



OUTLET

SCHNERZINGER **OUTLET** is a customary wall socket, whose contact pins undergo certain **ATOMIC BONDING** material structure processes.

Particularly for the operation of the **NEW INNOVATOR** and **OPERATOR** or **POWER MANAGER** the SCHNERZINGER **OUTLET** is indispensable.

It's available in the variants **INSTALLATION** and **SURFACE**.



Current should not flow against the contact pins formatting direction, thus it must be ensured that phase and neutral are connected correctly and not interchanged.

The connection for the phase is marked with "L". For proper connection, measure the phase on the power cable.

SCHNERZINGER®